



NOTES:

1. SIGN TYPES, SIZES AND COLORS PER PLAN OR SPECIFICATIONS.
2. INSTALL SIGNS, LIGHTBARS AND CABINETS WITH "BAND-IT" TOOL.
3. PUSHBUTTON SHALL BE WITHIN 10" REACH OF FACE OF CURB.
4. INSTALL POLE ONTO BASE USING STRAP WRENCH. TURN UNTIL SNUG AND POLE BOTTOMS OUT TO PREVENT MOVEMENT AND ROTATION DUE TO WIND.
5. SOLAR HARNESS SHALL BE ORIGINAL EQUIPMENT FROM THE MANUFACTURER AND SIZED LONG ENOUGH SO THAT THERE ARE NO SPLICES IN THE CABLE.
6. POLE PENETRATIONS SHALL BE MADE AS SMALL AS PRACTICAL AND UTILIZE GROMMETS WHEN APPROPRIATE TO PROTECT THE CABLE SHEATHING. EXCESS SPACE AROUND THE HOLES SHALL BE FILLED WITH RTV SEALANT.
7. PRECAST FOUNDATION MAY BE USED. SELECT FROM MATERIAL LIST.



RECTANGULAR  
RAPID FLASHING  
BEACON SYSTEM (RRFB)

CIVIL & UTILITY ENGINEERING

APPR. BY: SAW

DATE: 03.25

DRAWN BY: EY

DWG: TR7

CAD FILE: TR7\_3.2025